

BYD BATTERY-BOX PREMIUM QUICK START GUIDE



Valid for HVS 5.1/ 7.7/ 10.2/ 12.8

HVM 8.3/ 11.0/ 13.8/ 16.6/ 19.2/ 22.1



Please note that this is a Quick Start Guide only, which is a shortened assistance for the installation of the BYD Battery-Box Premium HVS/HVM. It does not replace the Operating Manual, which must be read and understood completely before installation. Please download and view it on this website: www.bydbatterybox.com.

Attention: High Voltage! Improper handling can pose a risk of electric shock and damage.

This guide and procedures described herein are intended for use by skilled workers only.

A skilled worker is defined as a trained and qualified electrician or installer who has all of the following skills and experience:

- Knowledge of the functional principles and operation of on-grid systems.
- Knowledge of the dangers and risks associated with installing and using electrical devices and acceptable mitigation methods.
- Knowledge of the installation of electrical devices.
- Knowledge of and adherence to this guide, the complete installation manual and all safety precautions and best practices.

In order to ensure the normal operation of the BYD Battery System, please download the app Be Connect 2.0 and then finish the configuration in accordance with this document.

If there are errors generated during the commissioning or operation, please read the Service Guideline and Checklist alongside this document, or digital version on the website.

If the battery system doesn't start at all, please contact BYD's local after-sales service team within 48 hours. Otherwise, the battery could be permanently damaged.

Please do not stack up batteries without protective packages when storing or handling batteries, except for installation.




Be Connect 2.0
Google Play




Be Connect 2.0
APP Store

1. Scope of Delivery



A

BCU




B

Base




J

M4x14 Countersunk
Screw




R

Female Power
Cable Coupler




S

Male Power
Cable Coupler



T


Terminal Resistor



C1


HVS Module

or




C2

HVM Module



D

Hanger (BCU Part)



E

Documents



F

Hanger (Wall Part)

x4



G

M5 Screw

x2



H

M6 Bolt and Nut

x4



I

Communication
Connector

x2



J

M4x14 Countersunk
Screw

2. Additionally Required Installation Materials



K

DC Cable
(6-10mm², double insulated)

x1



L

Expansion Anchor Bolt
(M8x40)




M

Cat5 Shield
(Metal Shielded RJ45 of Cat5 or higher)



N

PE-terminal



O

PE*
(10 mm²)



P

Heat Shrink Tubing

* Note: If the maximum current of the connected inverter is no more than 40 A, a grounding cable with a cross-sectional area of 6 mm² is also acceptable.

3. Tools



Network Wire Clamp




Marker




Phillips Screwdriver Bit




Flat-head Screwdriver



Torque Wrench




Wire Stripper



Hydraulic Plier



Wrench




Tape Measure




Drill




Heat Gun



Cylinder Screwdriver



Connector Wrench



Rubber Mallet



Crimping Pliers

4. Installation Location



Max +50 °C




Min -10 °C





RH. +5 %~ +95 %






5. Connection Limitation







$M = N$ ✓




$L = M = N$ ✓ $L \neq M$ or $l \neq N$ or $M \neq N$ ✗



≤ 3 (Towers)












✗





✗

6. Installation




7. Connection Diagram

Single Tower



- a INV Port for an inverter data cable
- b IN IN port for parallel tower connection
- c OUT OUT port for parallel tower connection
- d ETH Network port for connecting a router or network switch
- e PE Grounding cable connecting point
- f P- DC- to inverter
- g P+ DC+ to inverter








- 1.Parallel connection is not applicable to SMA Sunny Boy Storage 3.7-6.0. Please check the inverter's operating manual on how to connect up to three battery systems.
- 2.The length of the power cables from each tower to the combiner box should be the same.
- 3.The length of the power cable between each battery tower and the inverter should be less than 20 m.





8. Electrical Connections

NOTE: Before making all electrical connections, please make sure the air switch on the BCU is off.

8.1 PE Connection




8.2 DC Connection




NOTICE


- Any elastic piece of the terminal must be aligned with the thin-walled side of the plastic case opening before insertion;
- After inserting, please try pulling it out slightly to check if the terminal and the plastic case are securely connected.



8.3 Connecting the Data Cable to an Inverter



8.4 Connecting the Data Cable to a Router (It's not mandatory, but recommended)




8.5 Installing the Terminal Resistor







NOTICE

Parallel connection is not applicable to SMA Sunny Boy Storage 3.7-6.0.
Please check the inverter Operating Manual on how to connect up to three battery systems




9. Configuration


**1****2****3**




4




5



6



7




8



10. Switch ON/OFF Procedure

Switch ON/OFF Procedure



Battery WiFi will automatically shut off after five hours. Press the LED button once around one second or restart the system to activate it.




Switch On 1 → 2 → 3

Switch Off 3 → 4 → 1

11. Extension

Note: Within 5 days before extension, it is recommended to fully charge the original system to SOC 100% at least once.




- ① Measure the voltage of the new battery module, get a value (X).

	Voltage (X)/ V	SOC (Y)
HVS	$X < 100.80$	0~5%
	$100.80 \leq X < 103.20$	5~10%
	$103.20 \leq X < 103.68$	10~15%
	$103.68 \leq X < 104.54$	15~20%
	$104.54 \leq X < 105.41$	20~25%
	$105.41 \leq X$	25~30%
HVM	$X < 50.32$	0~5%
	$50.32 \leq X < 51.52$	5~10%
	$51.52 \leq X < 51.74$	10~15%
	$51.74 \leq X < 52.24$	15~20%
	$52.24 \leq X < 52.64$	20~25%
	$52.64 \leq X$	25~30%

- ② Refer to the above table to find out the SOC (Y) corresponding to the X.

New Battery
SOC $\approx$ Y



Original Battery
SOC $\approx$ Y



- ③ Charge or discharge the original battery system until the SOC is almost equal to Y, and then add the new battery module. Do not forget to do the configuration after that.

12. LED Status

Blinking white and blue
alternatively




The battery system is initiating

Solid white



Idle (the battery system is neither
charging nor discharging)

Blinking white slowly




The battery system is charging.

Blinking white quickly




The battery system is discharging

Blinking white and
solid blue




The battery system is discharging,
and the SOC is below 15%.

Blinking white and blue



An error has occurred (refer to
service guideline and checklist
for further details


13. Communication Options with Inverters




Designation of "INV" port

Pin	1	2	3	4
CAN/R5485	R5485A	R5485B	12V OUT	CAN H
Pin	5	6	7	8
CAN/R5485	CAN L	12V OUT_GND	EN	EN_GND


1 SMA SBS 2.5/ 3.7/ 5.0/ 6.0




2 SMA STP 5.0-10.0 SE




3 SMA SBSE 3.6 / 4.0 / 5.0 / 6.0




4 Kostal Plenticore Plus (G2/G3)/ Plenticore BI (G2/G3)




5 Kostal Piko MP Plus












6 Kostal Piko BA




7 Kaco blueplanet hybrid 6.0-10.0 TL3







17 GE GEH 5.0/ 8.6/ 10-1U-10




18 Solplanet




19 Western CO HHS 3000-6000/ HBS 3000-6000




20 Western CO HHT 5000-12000/ HBT 5000-12000




21 Sosen HI 3K-6K




22 GoodWe/ Viessmann/ Canadian Solar




23 Hoymiles




24 Afore AF(3-15)K-MTH




25 Afore AF(3-30)K-KH/ AF(3-12)K-KTH/ AF(3-17)K-KTHA




26 Maxhub PHN(5-10)KT-BH2



27 Kontron SolBrid 10-3-2/10-3-4



WLAN name, password and serial number.

A large, empty rectangular box with rounded corners and a red border, intended for input.



Twitter



Facebook



Linkedin



18436134-00

Global Service BYD Company limited



bboxservice@byd.com



+ 86 755 89888888-47175



No.3009, BYD Road, Pingshan, Shenzhen,
518118, P. R. China



www.bydbatterybox.com

Europe EFT-Systems GmbH



service@eft-systems.de



+ 49 9352 8523999 / +44 (0) 2037695998(UK)
+34 91 060 22 67(ES) / +39 02 87368364(IT)



Bruchtannenstr. 28, 63801 Kleinostheim, Germany



www.eft-systems.de

Australia Alps Power Pty Ltd



service@alpspower.com.au



+ 61 2 8005 6688



2/62 Belmore Road, Riverwood, NSW 2210



www.alpspower.com.au