

Zugstange für Umstellung mit Knopf 18 x 83 x 18 mm - Chrom

ERSATZTEILE

04 20 78 030 00



	Chrom	04 20 78 030 00-00
	Platin gebürstet	04 20 78 030 00-06
	Platin	04 20 78 030 00-08
	Messing (23kt Gold)	04 20 78 030 00-09
	Dark Brass matt	04 20 78 030 00-16
	Dark Bronze matt	04 20 78 030 00-17
	Messing gebürstet (23kt Gold)	04 20 78 030 00-28
	Cyprum	04 20 78 030 00-49
	Dark Platinum gebürstet	04 20 78 030 00-99



Zugstange für Umstellung mit Knopf 18 x 83 x 18 mm - Chrom

ERSATZTEILE

04 20 78 030 00



Zugstange für Umstellung mit Knopf 18 x 83 x 18 mm - Chrom

ERSATZTEILE

04 20 78 030 00