

Zugstange für Umstellung Ø 15 x 127,5 mm - Chrom

ERSATZTEILE

04 31 09 030 20



	Chrom	04 31 09 030 20-00
	Platin gebürstet	04 31 09 030 20-06
	Platin	04 31 09 030 20-08
	Messing (23kt Gold)	04 31 09 030 20-09
	Weiß matt	04 31 09 030 20-10
	schwarz	04 31 09 030 20-13
	Dark Brass matt	04 31 09 030 20-16
	Dark Bronze matt	04 31 09 030 20-17
	Dark Chrome	04 31 09 030 20-19
	Messing gebürstet (23kt Gold)	04 31 09 030 20-28
	Schwarz matt	04 31 09 030 20-33
	Champagne gebürstet (22kt Gold)	04 31 09 030 20-46
	Champagne (22kt Gold)	04 31 09 030 20-47
	Cyprum	04 31 09 030 20-49
	cyprum matt	04 31 09 030 20-56
	Dark Platinum gebürstet	04 31 09 030 20-99



Zugstange für Umstellung Ø 15 x 127,5 mm - Chrom

ERSATZTEILE

04 31 09 030 20



Zugstange für Umstellung Ø 15 x 127,5 mm - Chrom

ERSATZTEILE

04 31 09 030 20