


Griff Hebel Ø 45 x 30 mm - Chrom

ERSATZTEILE

09 20 87 042



Chrom

09 20 87 042-00



Platin gebürstet

09 20 87 042-06



Griff Hebel Ø 45 x 30 mm - Chrom

ERSATZTEILE

09 20 87 042



Griff Hebel Ø 45 x 30 mm - Chrom

ERSATZTEILE

09 20 87 042