


Griff für Umstellung Ø 28,5 x 19,5 mm - Chrom gebürstet

ERSATZTEILE

09 26 01 076



	Chrom gebürstet	09 26 01 076-93
	Chrom	09 26 01 076-00
	Platin gebürstet	09 26 01 076-06
	Platin	09 26 01 076-08
	Dark Brass matt	09 26 01 076-16
	Dark Bronze matt	09 26 01 076-17
	Dark Chrome	09 26 01 076-19
	Light Gold	09 26 01 076-26
	Light Gold gebürstet	09 26 01 076-27
	Messing gebürstet (23kt Gold)	09 26 01 076-28
	Schwarz matt	09 26 01 076-33
	Bronze gebürstet	09 26 01 076-42
	Champagne gebürstet (22kt Gold)	09 26 01 076-46
	Champagne (22kt Gold)	09 26 01 076-47
	Dark Platinum gebürstet	09 26 01 076-99



Griff für Umstellung Ø 28,5 x 19,5 mm - Chrom gebürstet

ERSATZTEILE

09 26 01 076



Griff für Umstellung Ø 28,5 x 19,5 mm - Chrom gebürstet

ERSATZTEILE

09 26 01 076