
Produced from: Jan.2026

CERABASE

Ideal Standard




Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961853AA	1 Set				
2	Rubber cap	B961951NU	3 Pcs.				
3	Rosette	B961431AA	1 Pcs.				
4	Screw M41x1.5	B962025NU	1 Set				
5	Cartridge Ø38mm	B961491NU*	1 Set				
6	Sealing set	B960784NU*	1 Set				
7	Perlator M22x1-A	B960828AA	1 Pcs.				
8	Rosette decorative	B961430AA	1 Pcs.				
9	O-Ring Ø37.77x2.62	A962574NU	1 Pcs.				
10	Connecting group	B960255NU	1 Set				
11	Fl.pexhose G3/8-L445mm	B960535NU	1 Pcs.				

Universal set (not all parts needed)

Produced from: May 2023

CERABASE

Ideal Standard



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961853AA	1 Set				
2	Rubber button	A963751NU	1 Pcs.				
3	Rosette	B961431AA	1 Pcs.				
4	Screw M41x1.5/M38x1.5	B961374NU	1 Set				
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	A861156NU*	1 Set				
7	Perlator M22x1-A	B960828AA	1 Pcs.				
8	Sealing set	B960784NU	1 Set				
9	Rosette decorative	B961430AA	1 Pcs.				
10	Fixation set	B960432NU	1 Set				
11	Fl.pexhose G3/8-L445mm	B960535NU	1 Pcs.				

**Universal set (not all parts needed)*