

Schieber für Brausegarnituren Ø 18 mm - Chrom

ERSATZTEILE

05 30 12 500 02



	Chrom	05 30 12 500 02-00
	Gold (23,9kt)	05 30 12 500 02-01
	altmessing	05 30 12 500 02-03
	chrom gebürstet (04)	05 30 12 500 02-04
	chrom edelmatt	05 30 12 500 02-05
	Platin gebürstet	05 30 12 500 02-06
	Platin	05 30 12 500 02-08
	Messing (23kt Gold)	05 30 12 500 02-09
	Weiß matt	05 30 12 500 02-10
	weiß	05 30 12 500 02-12
	schwarz	05 30 12 500 02-13
	Gold gebürstet (23,9kt)	05 30 12 500 02-14
	rot (15)	05 30 12 500 02-15
	Dark Brass matt	05 30 12 500 02-16
	Dark Bronze matt	05 30 12 500 02-17
	Dark Chrome	05 30 12 500 02-19
	Messing gebürstet (23kt Gold)	05 30 12 500 02-28
	Schwarz matt	05 30 12 500 02-33
	chrom satin	05 30 12 500 02-41
	aluminium (45)	05 30 12 500 02-45
	Champagne (22kt Gold)	05 30 12 500 02-47
	Cyprum	05 30 12 500 02-49
	Dark Platinum gebürstet	05 30 12 500 02-99



Schieber für Brausegarnituren Ø 18 mm - Chrom

ERSATZTEILE

05 30 12 500 02




Schieber für Brausegarnituren Ø 18 mm - Chrom

ERSATZTEILE

05 30 12 500 02

05 30 12 500 02



Ersatzteilstückliste

Nr.	Artikelnummer	Benennung	Verbaumenge	Lieferzeit
1	09 12 12 212 90	Steckhülse für Handbrause 25,08 x 33 x 26,04 mm -	1,00	2
3	08 18 40 514 90	Einsatz für Duschgarnitur 20 x 30 x 10 mm -	1,00	2
2	08 18 40 515 90	Hülse 20 x 35 x 20 mm -	1,00	2