


Griff Hebel Ø 10 x 30 mm - Chrom gebürstet

ERSATZTEILE

09 24 04 048



	Chrom gebürstet	09 24 04 048-93
	Chrom	09 24 04 048-00
	Gold (23,9kt)	09 24 04 048-01
	chrom gebürstet (04)	09 24 04 048-04
	Platin gebürstet	09 24 04 048-06
	Platin	09 24 04 048-08
	Messing (23kt Gold)	09 24 04 048-09
	Weiß matt	09 24 04 048-10
	Gold gebürstet (23,9kt)	09 24 04 048-14
	Dark Brass matt	09 24 04 048-16
	Dark Bronze matt	09 24 04 048-17
	Messing gebürstet (23kt Gold)	09 24 04 048-28
	Schwarz matt	09 24 04 048-33
	aluminium (45)	09 24 04 048-45
	Cyprum	09 24 04 048-49
	Dark Platinum gebürstet	09 24 04 048-99
	green	09 24 04 048-62



Griff Hebel Ø 10 x 30 mm - Chrom gebürstet

ERSATZTEILE

09 24 04 048



Griff Hebel Ø 10 x 30 mm - Chrom gebürstet

ERSATZTEILE

09 24 04 048